

Cylinder Pull Plate



1. Drill two thru holes on outside face of door for Sex Bolts use shown as the marks :

For Wood Door Application:
13/32" Dia. Drill Thru

- Note :**

1. For single door and double door with mullion use, the backset $2\frac{7}{16}"$ is to *face of stop*.
2. For double door without mullion use, the backset $2\frac{7}{16}"$ is to *edge of door*.